HOBBIT WARRANTY & ASSEMBLY GUIDE






ISO 9001:2015

nesthouz.com

Read the instruction carefully. Remove all the wrapping material. Staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure that you have all the parts before you start assembling. Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to prevent from scratches

CAUTION KEEP ALL THE PARTS OUT REACH OF CHILDREN

ITEM	HARDWARE LIST	QTY	SPARE
1	WOOD DOWEL M10 X 35MM	8	
(2)	JCBC SCREW M6 x 40MM (BLK)	E ()	
3	PAN HEAD SCREW	9	
4	M4 ALLEN KEY (BALL SHAPE) LONG	ï	
(5)	JCBC SCREW	ar≕i @ 4	
6	SPRING WASHER	Ø 4	
\overline{O}	FLAT WASHER	9 4	
(8)	AJUSTABLE SCREW	O 4	




HOBBIT WARRANTY & ASSEMBLY GUIDE


CODING -1329022 -1329023





ISO 9001:2015


nesthouz.com











2/2 nesthouz.com