

#### **CODING**

- -241030
- -241029
- -241032
- -241031



ISO 9001:2015

## nesthouz.com

Read the instruction carefully. Remove all the wrapping material. Staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure that you have all the parts before you start assembling. Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to prevent from scratches

### **CAUTION** KEEP ALL THE PARTS OUT REACH OF CHILDREN

HARDWARE LIST					
ITEM	DESCRIPTION			Spare Qty	
1	JCBC SCREW M6 X 50MM	(MINIMAN   100   1	6	1	
2	SCREW PIN	(70)	6	1	
3	SPRING WASHER M6	@	6	1	
4	L - BRACKET		4		
5	CSK CB SCREW M5 X 32MM		6		
6	CSK CB SCREW M3.5 X 12MM		8	2	
7	WOOD DOWEL M10 X 30MM		6	1	
8	ALLEN KEY M4 (BALL SHAPE)		1		

PART LIST					
ITEM	DESCRIPTION		QTY		
A	FRONT LEG	000	1		
В	BACK LEG	000	1		
С	SIDE RAIL (L&R)		2		
D	CHAIR SEAT		1		

# MISSIE WARRANTY & ASSEMBLY GUIDE

### **CODING**

- -241030
- -241029
- -241032 -241031



ISO 9001:2015 Reg. No. 000435-1-MY-1-OMS

## nesthouz.com













