MALMO

CODING
- 131141



ISO 9001:2015

nuhoom.com

Read the instructions carefully. Remove all the wrappings , staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

CAUTION
KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

HARDWARE		
A	MINI FIX A1 A2 A3	4 SETS
B	M8 X 30MM WOOD DOWEL	12 PCS
C	M6 X 50MM CSK CAP WOOD SCREW	4 PCS
D	ALLEN KEY M4	1 PC
E	PAN HEAD SCREW M4 X 12MM	4 PCS
F	METAL BRACKET	2 PCS
G	M3.5 X 16MM C.B SCREW	4 PCS
H	PVC HANDLE 7050.96	2 PCS
I	ROSE METAL LEG	4 PCS

SELF-PREPARED TOOLS: Tools below are NOT included in package.	
SCREWDRIVER	HAMMER

PART LIST		QTY
1	TOP PANEL	1 PC
2	BOTTOM PANEL	1 PC
3	SIDE PANEL (L)	1 PC
4	SIDE PANEL (R)	1 PC
5	BACK PANEL	1 PC
6	SLIDING DOOR	2 PCS

CODING
- 131141



ISO 9001:2015
Reg. No. 600455-1-MT-1-QMS

nuhoom.com



MALMO

CODING
- 131141



ISO 9001:2015

nuhoom.com

STEP 1

SCREWDRIVER REQUIRED

- Insert hardware **A2** onto panel **(1)**.
  (Repeat 4 times.)



STEP 2

SCREWDRIVER REQUIRED

- Insert hardware **B** onto panel **(3)**, **(4)** and **(5)**.
  (Repeat 12 times.)



STEP 3

SCREWDRIVER REQUIRED

- Insert hardware **A1** onto panel **(3)** and **(4)**.
- Attach panel **(3)**,**(4)** and **(5)** to panel **(1)**.
- Insert all hardware **A2** into **A1**.
- Rotate all **A1** until tight.
- Apply **A3** onto all **A1**.
  (Repeat 4 times.)



STEP 4

HARDWARE D

- Connect panel **(2)** to panel **(3)**, **(4)** and **(5)** by using hardware **C** and **D**.
  (Repeat 4 times.)



STEP 5

- Assemble part **(I)** into panel **(2)**.
  (Repeat 2 times for each Leg.)



STEP 6

SCREWDRIVER REQUIRED

- Fix hardware **H** onto panel **(6)** by using hardware **G**.
  (Repeat 2 times for each hardware.)